
DSO3000B—SCPI Protocol document

Ver: 1.0.0.4

May. 2016

SCPI COMMAND OVERVIEW.....	1
1. SYNTAX.....	1
2. SYMBOL DESCRIPTION	1
3. PARAMETER TYPE	2
OSCILLOSCOPE SECTION	4
1. CHANNEL COMMANDS	4
1.1 Bandwidth limitations <i>CHANnel<n>:BWLimit</i>	4
1.2 Channel Coupling <i>CHANnel<n>:COUPling</i>	4
1.3 Channel switch <i>CHANnel<n>:DISPlay</i>	5
1.4 Inverted waveform display <i>CHANnel<n>:INVert</i>	5
1.5 Waveform offset <i>CHANnel<n>:OFFSet</i>	6
1.6 Channel voltage range <i>CHANnel<n>:RANGe</i>	6
1.7 Channel voltage gear <i>CHANnel<n>:SCALE</i>	7
1.8 Channel probe ratio <i>CHANnel<n>:PROBe</i>	7
2. TIMEBASE COMMANDS	8
2.1 Main timebase offset <i>TIMebase:MAIN:OFFSet</i>	8
2.2 Main timebase scale <i>TIMebase:MAIN:SCALE</i>	9
3. TRIGGER COMMANDS.....	9
3.1 Trigger mode <i>TRIGger:MODE</i>	9
3.2 Trigger time <i>TRIGger:TIME</i>	10
3.3 Trigger status <i>TRIGger:STATus?</i>	10
3.4 Trigger sweep <i>TRIGger:SWEEp</i>	10
3.5 Edge-triggered trigger source <i>TRIGger:EDGE:SOURce</i>	11
3.6 Edge trigger polarity <i>TRIGger:EDGE:POLarity</i>	11
3.7 Edge trigger level <i>TRIGger:EDGE:LEVel</i>	12

3.8 Trigger pulse source	TRIGger:PULSe:SOURce	12
3.9 Pulse Trigger conditions	TRIGger:PULSe:WHEN	13
3.10 Trigger pulse width trigger value	TRIGger:PULSe:WIDth	13
3.11 Pulse trigger polarity	TRIGger: PULSe:POLarity	13
3.12 Pulse Trigger level	TRIGger:PULSe:LEVel	14
3.13 Trigger Slope trigger source	TRIGger:SLOPe:SOURce	14
3.14 Slope Trigger trigger condition	TRIGger:SLOPe:WHEN	15
3.15 Slope Trigger trigger time	TRIGger:SLOPe:TIME	15
3.16 Slope trigger alevel	TRIGger:SLOPe:ALEVel	15
3.17 Slope trigger blevel	TRIGger:SLOPe:BLEVel	16
3.18 Slope trigger polarity	TRIGger:SLOPe:POLarity	16
3.19 Trigger slope width trigger value	TRIGger:SLOPe:WIDth	17
3.20 Trigger video trigger source	TRIGger:VIDeo:SOURce	17
3.21 Video trigger mode	TRIGger:VIDeo:MODE	18
3.22 Video trigger time	TRIGger:VIDeo:TIME	18
3.23 Video trigger level	TRIGger:VIDeo:LEVel	18
3.24 Video trigger polarity	TRIGger:VIDeo:POLarity	19
3.25 Video trigger line	TRIGger:VIDeo:LINE	19
3.26 Video trigger standard	TRIGger:VIDeo:STANdard	20
3.27 Timeout trigger source	TRIGger:TIMeout:SOURce	20
3.28 Timeout trigger width	TRIGger:TIMeout:WIDth	21
3.29 Timeout trigger time	TRIGger:TIMeout:TIME	21
3.30 Timeout trigger level	TRIGger:TIMeout:LEVel	21
3.31 Timeout trigger polarity	TRIGger:TIMeout:POLarity	22
4. ACQUIRE COMMANDS		22
4.1 Acquire mode	ACQuire:MODE	22
4.2 Acquire depth	ACQuire:MDEPth	23
4.3 Acquire stop	ACQuire:STOP	24
5. SELF-CALIBRATION COMMANDS		24
5.1 Calibrate start	CALibrate:STARt	24

5.2 Calibrate state	CALibrate:STATE ?	24
5.3 Calibrate stop	CALibrate:STOP	25
6.	AUTOSET	25
7.	RUN/STOP SETTING	26
8.	RESET *RST	26
9.	SINGLE TRIGGER SINGLE:TRIG	27
10.	GET ALL OF THE ONE-TIME PARAMETER SETTING STATE SETUP:ALL?	27
11.	WAVEFORM	30
11.1	Get display data WAVEform:DATA:DISP	30
11.2	Get all the data WAVEform:DATA:ALL	31
12.	SYSTEM	31
12.1	Modify the system IP address SYSTEM:IP	31
12.2	Get the system version number SYSTEM:VERSion?	32
SOURCE SECTION		33
1.	SET AND QUERY THE STATUS OF SOURCE CHANNEL SOURCE:OUTPUT	33
2.	SET AND QUERY THE TYPE OF SOURCE CHANNEL SOURCE:FUNCTION:TYPE	33
3.	SET AND QUERY THE FREQUENCY OF SOURCE CHANNEL SOURCE:OUTPUT:FREQUENCY	34
4.	SET AND QUERY THE AMP OF SOURCE CHANNEL SOURCE:OUTPUT:AMP	34
5.	SET AND QUERY THE OFFSET OF SOURCE CHANNEL SOURCE:OUTPUT:OFFSET	35
6.	SET AND QUERY THE DUTY OF SOURCE CHANNEL SOURCE:OUTPUT:DUTY	35
7.	SET AND QUERY THE TRAPEZOIDAL WAVE RISES DUTY OF SOURCE CHANNEL	
	SOURCE:OUTPUT:TRAPE:DUTY:RISE...	
	36
8.	SET AND QUERY THE TRAPEZOIDAL WAVE FALLS DUTY OF SOURCE CHANNEL	
	SOURCE:OUTPUT:TRAPE:DU	
	TY:FALL 36
9.	SET AND QUERY THE TRAPEZOIDAL WAVE HIGH DUTY OF SOURCE CHANNEL	
	SOURCE:OUTPUT:TRAPE:DUT	
	Y:HIGH 37

10. SET AND QUERY THE EXP TYPE OF SOURCE CHANNEL	SOURCE:OUTPUT:EXP:TYPE.....	37
11. SET AND QUERY OUTPUT SIGNAL SOURCE EXP SPIKE ACCOUNTED FOR A PROPORTION OF THE CYCLE TIME		
SOURCE:OUTPUT:EXP:T		38
12. SET AND QUERY THE AM/FM TYPE OF SOURCE CHANNEL	SOURCE:OUTPUT:AM/FM:TYPE	38
13. SET AND QUERY THE AM/FM HIGH FREQUENCY OF SOURCE CHANNEL	SOURCE:OUTPUT:AM/FM:FO...	39
14. SET AND QUERY THE AM/FM MODULATION DEPTH OF SOURCE CHANNEL	SOURCE:OUTPUT:AM/FM:D EPTH	39
15. SET AND QUERY THE AM/FM MAXIMFREQ OF SOURCE CHANNEL	SOURCE:OUTPUT:AM/FM:MAXIMFREQ	40
16. TRIGGER SIGNAL SOURCE	SOURCE:TRIGGER:SOURCE.....	40
17. POLARITY OF EXTERNAL TRIGGER SOURCE	SOURCE:TRIGGER:EXTER:SLOPE.....	41
18. TRIGGER STATUS OF SOURCE	SOURCE:TRIGGER:CONTINUE	41
19. CLEAR EXTERNAL TRIGGER SIGNAL SOURCE	SOURCE:TRIGGER:EXTER:CLEAR.....	42
20. TRIGGER SIGNAL SOURCE	SOURCE:TRIGGER	42
21. SOURCE SYNC	SOURCE:SYNC	42
22. ARBITRARY WAVE FREQUENCY SIGNAL	SOURCE:FUNCTION:ARB:FREQUENCY.....	43
23. SOURCE OF ARBITRARY WAVE DOWNLOAD POINTS	SOURCE:FUNCTION:ARB:POINT?	43
24. ARBITRARY WAVE SIGNAL DATA DOWNLOAD	SOURCE:DATA:ARB:DAC16:BIN	44
25. GET ALL OF THE SOURCE PARAMETER SETTING STATUS	SOURCE:SETUP:ALL?	44
WORD GENERATOR SECTION		46
1. SET AND QUERY THE STATUS OF WORD GENERATOR	WORD:OUTPUT	46
2. SET AND QUERY THE FEATURES OF WORD GENERATOR	WORD:FUNCTION.....	46
3. SET AND QUERY THE PROGRAMMED OF VALUE WORD GENERATOR	WORD:PROGRAM.....	47
LOGIC ANALYZERS SECTION		48
1. LA D0-D7 SWITCH STATUS	LA:POD1:STATE.....	48
2. LA D8-D15 SWITCH STATUS	LA:POD2:STATE	48
3. LA CUSTOM THRESHOLD VOLTAGE	LA:POD1:THRESHOLD:USERVOLT	49

4. LA CUSTOM THRESHOLD VOLTAGE	LA:POD2:THRESHOLD:USERVOLT	49
5. LA DIGITAL CHANNELS D0-D15 SWITCH STATUS	LA:SOURCE	50
APPENDIX.....		51
SCPI	AGREEMENT REMARKS:	51

SCPI Command Overview

SCPI (Standard Commands for Programmable Instruments) It defines a set of programmable test and measurement instruments for controlling the standard syntax and commands. SCPI commands are ASCII strings, instrument passed through the physical transport layer. Chain of command keywords constitution, and some also need to include parameters. In the agreement, the command is defined as follows: CONFigure. In use, which you can write the full name, or you can just write the abbreviation contains only uppercase letters. Typically instrument for query feedback for ASCII code. When transferring large amounts of data, binary data can also be used.

1. Syntax

The command string usually starts with ":"; the keywords are separated by ":" and are followed by the parameter settings available; "?" is added at the end of the command string to indicate query; the command keywords and the first parameter are separated by space.

For example,

```
CHANnel1:BWLimit 20M
```

```
CHANnel1:BWLimit?
```

CHANnel1 is the root keyword of the command. BWLimit is the second-level keyword. The command string starts with ":" which is also used to separate the multiple-level keywords. 20M represents the parameters available for setting. "?" represents query.

2. Symbol Description

The following symbols will not be sent with the commands.

1. Braces {}

The parameters enclosed in the braces are optional and are usually separated by the vertical bar "|". When using the command, one of the parameters must be selected.

2. Vertical Bar |

The vertical bar is used to separate multiple parameters and one of the parameters must be selected when using the command.

3. Square Brackets []

The content in the square brackets can be omitted.

4. Triangle Brackets <>

The parameter enclosed in the triangle brackets must be replaced by an effective value.

3. Parameter Type

1、bool

The parameter could be 0, 1, OFF or ON. For example,

RUNning <bool>

RUNning?

Wherein,<bool>can be set to{ON}|{OFF}.

The query returns ON or OFF.

2、Discrete

The parameter could be any of the values listed. For example,

CHANnel1:COUPling <type>

CHANnel1:COUPling?

Wherein,

<type>can be set to GND | DC | AC。

The query returns the abbreviations GND、DC 或 AC

3、Integer

Do not use decimals parameter settings, otherwise an exception occurs.

4、Real

The parameter can be any real number, return the effective value range. For example,

CHANnel1:PROBe <atten>

CHANnel1:PROBe?

Wherein,

atten can be set to any real number 10, The query returns a real number in scientific notation: 1.000000e+01

5、String

The parameter should be the combinations of characters. For example,

SET:Serial <license>

Wherein,

<license> can be set to D43000518。

4、Command Abbreviation

All the commands are case-insensitive and you can use any of them. If abbreviation is used, all the capital letters in the command must be written completely.

For example,

CHANnel1:BWLimit? can be abbreviated to CHAN:BWL?

Oscilloscope section

1. CHANnel Commands

1.1 Bandwidth limitations CHANnel<n>: BWLimit

Syntax	CHANnel<n>:BWLimit <type> CHANnel<n>:BWLimit?
Description	Set or query the bandwidth limit parameter of the specified channel.
Parameter	<n> Discrete {1 2 3 4} <type> Discrete {20M OFF}
Explanation	OFF: disable the bandwidth limit and the high frequency components of the signal under test can pass the channel. 20M: enable the bandwidth limit and the high frequency components of the signal under test that exceed 20 MHz are attenuated
Return	The query returns 20M or OFF.
For example	<pre>CHANnel1:BWLimit 20M /*Enable the 20MHz bandwidth limit*/ CHANnel1:BWLimit? /*The query returns 20M*/</pre>

1.2 Channel Coupling CHANnel<n>:COUPling

Syntax	CHANnel<n>:COUPling <coupling> CHANnel<n>:COUPling?
Description	Set or query the coupling mode of the specified channel.
Parameter	<n> Discrete {1 2 3 4} <coupling> Discrete {AC DC GND} Default: DC
Explanation	AC : the DC components of the signal under test are

blocked.

DC : the DC and AC components of the signal under test can both pass the channel.

GND: the DC and AC components the signal under test are both blocked.

Return The query returns AC,DC or GND

For example

```
CHANnel1:COUPling AC      /*Select the AC coupling mode*/  
CHANnel1:COUPling?      /*The query returns AC*/
```

1.3 Channel switch **CHANnel<n>:DISPlay**

Syntax CHANnel<n>:DISPlay <bool>

CHANnel<n>:DISPlay?

Description Enable or disable the specified channel or query the status of the specified channel.

Parameter <n> Discrete {1|2|3|4}
<bool> Bool {{OFF}}|{ON}}

Explanation

Return The query returns ON or OFF.

For example CHANnel1:DISPlay ON /*Enable CH1*/
CHANnel1:DISPlay? /*The query returns ON*/

1.4 Inverted waveform display **CHANnel<n>:INVert**

Syntax CHANnel<n>:INVert <bool>

CHANnel<n>:INVert?

Description Enable or disable the waveform invert of the specified channel or query the status of the waveform invert of the specified channel.

Parameter <n> Discrete {1|2|3|4}

<bool> Bool {{OFF}}|{ON}}

Explanation When waveform invert is turned off, the waveform display is normal; when waveform invert is turned on, the waveform voltage values are inverted.

Return The query returns ON or OFF

For example

```
CHANnel1:INVert ON /*Enable the waveform invert of CH1*/
CHANnel1:INVert? /*The query returns ON*/
```

1.5 Waveform offset **CHANnel<n>:OFFSet**

Syntax CHANnel<n>:OFFSet <offset>
CHANnel<n>:OFFSet?

Description Set or query the vertical offset of the specified channel.
The default unit is V.

Parameter <n> Discrete {1|2|3|4}
<offset> Real Related to the current vertical scale and probe ratio, When the probe ratio is 1X
Vertical Scale: Voltage gear value mV/div: (-Voltage gear value x 5) to (+Voltage gear value x 5)

Return The query returns the vertical offset in scientific notation.

For example

```
CHANnel1:OFFSet 0.01 /*Set the vertical offset of CH1 to 10mV*/
CHANnel1:OFFSet? /*The query return 0.01*/
```

1.6 Channel voltage range **CHANnel<n>:RANGe**

Syntax CHANnel<n>:RANGe <range>
CHANnel<n>:RANGe?

Description Set or query the vertical range of the specified channel.
The default unit is V.

Parameter	<n>	Discrete {1 2 3 4}
	<range>	Real Related to the probe ratio,When the probe ratio is 1X:1mV to 10V
Explanation	This command indirectly modifies the vertical scale of the specified channel.	
Return	The query returns the vertical range in scientific notation.	
For example	<pre>CHANnel1:RANGe 1 /*Set the vertical range of CH1to 1V*/ CHANnel1:RANGe? /*The query returns 1.000e+00*/</pre>	

1.7 Channel voltage gear **CHANnel<n>:SCALE**

Syntax	CHANnel<n>:SCALE <scale>	
	CHANnel<n>:SCALE?	
Description	Set or query the vertical scale of the specified channel. The default unit is V.	
Parameter	<n>	Discrete {1 2 3 4}
	<scale>	Real Related to the probe ratio, When the probe ratio is 1X:1mV to 10V
Explanation		
Return	The query returns the vertical scale in scientific notation.	
For example	<pre>CHANnel1:SCALE 1 /* Set the vertical scale of CH1to 1V*/ CHANnel1:SCALE? /* The query returns 1.000e+00*/</pre>	

1.8 Channel probe ratio **CHANnel<n>:PROBE**

Syntax	CHANnel<n>:PROBE <atten>	
	CHANnel<n>:PROBE?	

Description	Set or query the probe ratio of the specified channel.
Parameter	<n> Discrete {1 2 3 4}
	<atten> Discrete { 1 10 100 1000 } Default: 10
Explanation	Setting the probe ratio refers to multiply the signal sampled with the specified ratio and then display the result (the actual amplitude of the signal will not be affected). Setting the probe ratio will affect the range of the vertical scale.
Return	The query returns the vertical scale in scientific notation.
For example	
	CHANnel1:PROBe 10 /*Set the probe ratio of CH1 to 10*/
	CHANnel1:PROBe? /*The query returns 1.000e+01*/

2. TIMEbase Commands

2.1 Main timebase offset TIMEbase:MAIN:OFFSet

Syntax	TIMEbase:MAIN:OFFSet <offset> TIMEbase:MAIN:OFFSet?
Description	Set or query the main timebase offset. The default unit is s.
Parameter	<offset> Real -Screen/2 to 1s or -Screen/2 to 5000s
Explanation	--Roll mode RUN: This command is invalid. STOP: This command is invalid. --YT mode RUN:Timebase >= 200ms(namely the "Slow Sweep"). STOP: This command is invalid.
Return	The query returns the main timebase offset in scientific notation.
For example	
	TIMEbase:MAIN:OFFSet 0.0002 /*Set the main timebase offset to 200ms*/
	TIMEbase:MAIN:OFFSet? /*The query returns 2.000000e-04*/

2.2 Main timebase scale **TIMEbase:MAIN:SCALE**

Syntax	TIMEbase:MAIN:SCALE <scale_value> TIMEbase:MAIN:SCALE?
Description	Set or query the main timebase scale. The default unit is s/div
Parameter	<scale_value> Real
Explanation	When the horizontal timebase mode is YT and the horizontal timebase is 200ms/div or larger (namely the “Slow Sweep” mode), this command is invalid when the oscilloscope is in the transition to the “Stop” state.
Return	The query returns the main timebase scale in scientific notation.

For example

```
TIMEbase:MAIN:SCALE 0.0002 /*Set the main timebase scale to 200ms/div*/  
TIMEbase:MAIN:SCALE? /* The query returns 2.000000e-04*/
```

3. TRIGger Commands

3.1 Trigger mode **TRIGger:MODE**

Syntax	TRIGger:MODE <mode> TRIGger:MODE?
Description	Select or query the trigger type
Parameter	<mode> Discrete EDGE PULSE VIDeo SLOPe TIMEout
Explanation	
Return	The query returns EDGE、PULSE、VIDeo、SLOPe、TIMEout

For example

```
TRIGger:MODE SLOPe /*Select slope trigger*/  
TRIGger:MODE? /*The query returns SLOPe*/
```

3.2 Trigger time **TRIGger:TIME**

Syntax TRIGger:TIME <time>
TRIGger:TIME?

Description Trigger time is the timing of trigger offset

Parameter <time> Real

Explanation The default unit is S

Return

For example

```
TRIGger:TIME 0.000003 /*Set trigger time is 3us*/  
TRIGger:TIME? /* The query returns 3.000000e-06*/
```

3.3 Trigger status **TRIGger:STATus?**

Syntax TRIGger:STATus?

Description Query the current trigger status.

Return The query returns TRIGed(Have triggered), NOTRIG(No trigger)

For example TRIGger:STATus?

3.4 Trigger sweep **TRIGger:SWEEp**

Syntax TRIGger:SWEEp <mode>
TRIGger:SWEEp?

Description Set or query the trigger mode.

Parameter <mode> Discrete {AUTO|NORMal|SINGLE}

Explanation AUTO: auto trigger. NO matter whether the trigger condition is met, there is always waveform display.
NORMal: normal trigger. Display waveform when the trigger condition is met; otherwise, the oscilloscope holds the original waveform and waits for the next trigger.

SINGle: single trigger. The oscilloscope wait for a trigger and displays the waveform when the trigger condition is met and then stops.

Return The query returns AUTO; NORMal; SINGle.

For example TRIGger:SWEEp SINGle /*Select single trigger mode*/
TRIGger:SWEEp? /*The query returns SINGle*/

3.5 Edge-triggered trigger source TRIGger:EDGE:SOURce

Syntax TRIGger:EDGE:SOURce <source>

TRIGger:EDGE:SOURce?

Description Set or query the trigger source in edge trigger.

Parameter

<source>Discrete{CHANnel1|CHANnel2|CHANnel3|CHANnel4|EXT/10 }

Explanation

Return The query returns CHANnel1、CHANnel2、CHANnel3、CHANnel4 or EXT/10

For example

TRIGger:EDGE:SOURce CHANnel1 /*Set the trigger source CH1*/
TRIGger:EDGE:SOURce? /*The query returns CHANnel1 */

3.6 Edge trigger polarity TRIGger:EDGE:POLarity

Syntax TRIGger:EDGE:POLarity <slope>

TRIGger:EDGE:POLarity?

Description Set or query the edge polarity in edge trigger.

Parameter <slope> Discrete {POSITIVE|NEGATIVE|RFALL}

Explanation POSITIVE: rising edge

NEGATIVE: falling edge

RFALL: rising/falling edge

Return The query returns "POSITIVE", "NEGATIVE", "RFALL"

For example

```
TRIGger:EDGE:POLarity NEGAtive /*Set the edge type to falling edge*/
```

```
TRIGger:EDGE:POLarity? /*The query returns NEGAtive */
```

3.7 Edge trigger level TRIGger:EDGE:LEVel

Syntax TRIGger:EDGE:LEVel <level>

TRIGger:EDGE:LEVel?

Description Set or query the trigger level in edge trigger. The unit is the same as the current amplitude unit of the signal source selected.

Parameter <level> Real

Explanation

Return The query returns the trigger level in scientific notation.

For example

```
TRIGger:EDGE:LEVel 0.16 /*Set the trigger level to 160mV*/
```

```
TRIGger:EDGE:LEVel? /*The query returns 1.600000e-01 */
```

3.8 Trigger pulse source TRIGger:PULSe:SOURce

Syntax TRIGger:PULSe:SOURce <source>

TRIGger:PULSe:SOURce?

Description Set or query the trigger source in pulse width trigger.

Parameter

<source> Discrete {CHANnel1|CHANnel2|CHANnel3|CHANnel4}

Explanation

Return The query returns CHANnel1,CHANnel2,CHANnel3 or CHANnel4

For example

```
TRIGger:PULSe:SOURce CHANnel1 /*Set the trigger source to CH1*/
```

```
TRIGger:PULSe:SOURce? /*The query returns CHANnel1 */
```

3.9 Pulse Trigger conditions TRIGger:PULSe:WHEN

Syntax TRIGger:PULSe:WHEN <when>
TRIGger:PULSe:WHEN?

Description Set or query the trigger condition in pulse width trigger.

Parameter <when> Discrete "EQUAL", "NEQUAl", "GREAT", "LESS"

Explanation

Return The query returns "EQUAL", "NEQUAl", "GREAT", "LESS"

For example

```
TRIGger:PULSe:WHEN EQUAL /*Set the trigger condition to EQUAL */  
TRIGger:PULSe:WHEN? /* The query returns EQUAL */
```

3.10 Trigger pulse width trigger value TRIGger:PULSe:WIDth

Syntax TRIGger:PULSe:WIDth <width>
TRIGger:PULSe:WIDth?

Description Set or query the pulse width in pulse width trigger. The default unit is s

Parameter <width> Real.

Explanation

Return The query returns the pulse width in scientific notation.

For example

```
TRIGger:PULSe:WIDth 0.000003 /*Set the pulse width to 3us*/  
TRIGger:PULSe:WIDth? /* The query returns 3.000000e-06*/
```

3.11 Pulse trigger polarity TRIGger: PULSe:POLarity

Syntax TRIGger:PULSe:POLarity <polarity>
TRIGger:PULSe:POLarity?

Description Set or query the edge type in pulse width trigger.

Parameter <polarity> Discrete POSItive NEGAtive

Explanation**Return** The query returns POSitive or NEGative**For example**

TRIGger:PULSe:POLarity POSitive/* Set the pulse polarity to POSitive*/

TRIGger:PULSe:POLarity? /* The query returns POSitive */

3.12 Pulse Trigger level TRIGger:PULSe:LEVel

Syntax TRIGger:PULSe:LEVel <level>

TRIGger:PULSe:LEVel?

Description Set or query the trigger level in pulse width trigger. The unit is the same as the current amplitude unit.**Parameter** <level> Real**Explanation****Return** The query returns the trigger level in scientific notation.**For example**

TRIGger:PULSe:LEVel 0.16 /*Set the trigger level to 160mV*/

TRIGger:PULSe:LEVel? /* The query returns 1.600000e-01*/

3.13 Trigger Slope trigger source TRIGger:SLOPe:SOURce

Syntax TRIGger:SLOPe:SOURce <source>

TRIGger:SLOPe:SOURce?

Description Set or query the trigger source in slope trigger.**Parameter**

<source> Discrete {CHANnel1|CHANnel2|CHANnel3|CHANnel4}

Explanation**Return** The query returns CHANnel1,CHANnel2,CHANnel3 or CHANnel4**For example**

TRIGger:SLOPe:SOURce CHANnel1/*Set the trigger source to CH1*/

TRIGger:SLOPe:SOURce? /* The query returns CHANnel1 */

3.14 Slope Trigger trigger condition TRIGger:SLOPe:WHEN

Syntax TRIGger:SLOPe:WHEN <when>

TRIGger:SLOPe:WHEN?

Description Set or query the trigger condition in slope trigger.

Parameter <when> Discrete "EQUAL, "NEQUal"GREAT,"LESS"

Explanation

Return The query returns "EQUAL, "NEQUal"GREAT,"LESS"

For example

TRIGger:SLOPe:WHEN EQUAL /*Set the trigger condition to EQUAL */

TRIGger:SLOPe:WHEN? /* The query returns EQUAL */

3.15 Slope Trigger trigger time TRIGger:SLOPe:TIME

Syntax TRIGger:SLOPe:TIME <time>

TRIGger:SLOPe:TIME?

Description Set or query the time value in slope trigger. The default unit is s

Parameter <time> Real

Explanation

Return The query returns the times value in scientific notation.

For example TRIGger:SLOPe:TIME 0.000003 /*Set the time value to 3us*/

TRIGger:SLOPe:TIME? /*The query returns 3.000000e-06*/

3.16 Slope trigger alevel TRIGger:SLOPe:ALEVel

Syntax TRIGger:SLOPe:ALEVel <level>

TRIGger:SLOPe:ALEVel?

Description Set or query upper level value in slope trigger. The unit is

the same as the current amplitude unit.

Parameter <level> Real

Explanation

Return The query returns the upper level value in scientific notation.

For example

```
TRIGger:SLOPe:ALEVel 0.16 /* Set the trigger level to 160mV*/
TRIGger:SLOPe:ALEVel? /* The query returns 1.600000e-01*/
```

3.17 Slope trigger blevel TRIGger:SLOPe:BLEVel

Syntax TRIGger:SLOPe:BLEVel <level>
TRIGger:SLOPe:BLEVel?

Description Set or query down level value in slope trigger. The unit is the same as the current amplitude unit.

Parameter <level> Real

Explanation

Return The query returns the down level value in scientific notation.

For example

```
TRIGger:SLOPe:BLEVel 0.16 /* Set the trigger level to 160mV*/
TRIGger:SLOPe:BLEVel? /* The query returns 1.600000e-01*/
```

3.18 Slope trigger polarity TRIGger:SLOPe:POLarity

Syntax TRIGger:SLOPe:POLarity <polarity>
TRIGger:SLOPe:POLarity?

Description Set or query the edge type in slope trigger.

Parameter <polarity> Discrete {POSitive|NEGAtive}

Explanation

Return The query returns POSitive NEGAtive

For example

TRIGger:SLOPe:POLarity NEGAtive/*Set the pulse polarity to NEGAtive*/

TRIGger:SLOPe:POLarity? /* The query returns NEGAtive */

3.19 Trigger slope width trigger value TRIGger:SLOPe:WIDth

Syntax TRIGger:SLOPe:WIDthwidth>

TRIGger:SLOPe:WIDth

Description Set or query the slope width in pulse width trigger. The default unit is s

Parameter <width> Real

Explanation

Return The query returns the pulse width in scientific notation.

For example

TRIGger:SLOPe:WIDth 0.000003 /* Set the pulse width to 3us*/

TRIGger:SLOPe:WIDth? /*The query returns 3.000000e-06*/

3.20 Trigger video trigger source TRIGger:VIDeo:SOURce

Syntax TRIGger:VIDeo:SOURce <source>

TRIGger:VIDeo:SOURce?

Description Set or query the trigger source in video trigger.

Parameter

<source> Discrete {CHANnel1|CHANnel2|CHANnel3|CHANnel4}

Explanation

Return The query returns CHANnel1,CHANnel2,CHANnel3 or CHANnel4

For example

TRIGger:VIDeo:SOURce CHANnel1/* Set the trigger source to CH1*/

TRIGger:VIDeo:SOURce? /*The query returns CHANnel1 */

3.21 Video trigger mode **TRIGger:VIDeo:MODE**

Syntax TRIGger:VIDeo:MODE <mode>

TRIGger:VIDeo:MODE?

Description Set or query the sync type in video trigger.

Parameter

<mode> Discrete {SCANLINE|LINENUM|ODDFIELD|EVENFIELD|ALLFIELD}

Explanation SCANLINE Scan line

LINENUM Line Number

ODDFIELD Odd field

EVENFIELD Even field

ALLFIELD All Fields

Return

For example TRIGger:VIDeo:MODE SCANLINE /*Set the sync type to SCANLINE*/

TRIGger:VIDeo:MODE? /* The query returns SCANLINE*/

3.22 Video trigger time **TRIGger:VIDeo:TIME**

Syntax TRIGger:VIDeo:TIME <time>

TRIGger:VIDeo:TIME?

Description Set or query the time value in video trigger.

Parameter <time> Real

Explanation The default unit is S

Return

For example TRIGger:VIDeo:TIME 0.000003 /*Set the video value to 3 μ s*/

TRIGger:VIDeo:TIME? /* The query returns 3.000000e-06*/

3.23 Video trigger level **TRIGger:VIDeo:LEVel**

Syntax TRIGger:VIDeo:LEVel <level>

TRIGger:VIDeo:LEVel?

Description Set or query video level value in slope trigger. The unit is the same as the current amplitude unit.

Parameter <level> Real

Explanation

Return The query returns the video level value in scientific notation.

For example

```
TRIGger:VIDeo:LEVel 0.16 /* Set the trigger level to 160mV*/
TRIGger:VIDeo:LEVel? /* The query returns 1.600000e-01*/
```

3.24 Video trigger polarity **TRIGger:VIDeo:POLarity**

Syntax TRIGger:VIDeo:POLarity <polarity>
TRIGger:VIDeo:POLarity?

Description Set or query the edge type in video trigger.

Parameter <polarity> Discrete POSItive NEGAtive

Explanation

Return The query returns POS or NEG

For example

```
TRIGger:VIDeo:POLarity POSItive /* Set the pulse polarity to POSTive*/
TRIGger:VIDeo:POLarity? /* The query returns POSItive */
```

3.25 Video trigger line **TRIGger:VIDeo:LINE**

Syntax TRIGger:VIDeo:LINE <line>
TRIGger:VIDeo:LINE?

Description Set or query the line number when the sync type in video trigger is LINE.

Parameter <line> Integer

Explanation NTSC: 1 to 525
PAL/SECAM: 1 to 625

Return The query returns an integer.

For example

```
TRIGger:VIDeo:LINE 100 /*Set the line number to 100*/  
TRIGger:VIDeo:LINE? /* The query returns 100*/
```

3.26 Video trigger standard **TRIGger:VIDeo:STANdard**

Syntax TRIGger:VIDeo:STANdard <standard>

TRIGger:VIDeo:STANdard?

Description Set or query the video standard in video trigger.

Parameter <standard> Discrete { NTSC | PAL/SECAM }

Explanation

Return

For example

```
TRIGger:VIDeo:STANdard NTSC/*Select NTSC video standard*/  
TRIGger:VIDeo:STANdard? /* The query returns NTSC*/
```

3.27 Timeout trigger source **TRIGger:TIMEout:SOURce**

Syntax TRIGger:TIMEout:SOURce <source>

TRIGger:TIMEout:SOURce?

Description Set or query the trigger source in timeout trigger.

Parameter

<source> Discrete { CHANnel1 | CHANnel2 | CHANnel3 | CHANnel4 }

Explanation

Return The query returns CHANnel1, CHANnel2, CHANnel3 or CHANnel4

For example

```
TRIGger:TIMEout:SOURce CHANnel1/* Set the trigger source to CH1*/  
TRIGger:TIMEout:SOURce? /* The query returns CHANnel1 */
```

3.28 Timeout trigger width TRIGger:TIMEout:WIDth

Syntax TRIGger:TIMEout:WIDth<width>
TRIGger:TIMEout:WIDth?

Description Set or query the timeout width in timeout trigger. The default unit is s

Parameter <width> Real

Explanation

Return The query returns the pulse width in scientific notation.

For example

```
TRIGger:TIMEout:WIDth 0.000003 /* Set the pulse width to 3us*/  
TRIGger:TIMEout:WIDth? /* The query returns 3.000000e-06*/
```

3.29 Timeout trigger time TRIGger:TIMEout:TIME

Syntax TRIGger:TIMEout:TIME <NR3>
TRIGger:TIMEout:TIME?

Description Set or query the timeout time in timeout trigger. The default unit is s

Parameter <NR3> Real

Explanation The query returns the timeout time in scientific notation.

Return

For example

```
TRIGger:TIMEout:TIME 0.002 /*Set the timeout time to 2ms*/  
TRIGger:TIMEout:TIME? /* The query returns 2.000000e-03*/
```

3.30 Timeout trigger level TRIGger:TIMEout:LEVel

Syntax TRIGger:TIMEout:LEVel <level>
TRIGger:TIMEout:LEVel?

Description Set or query the trigger level in timeout trigger. The unit is

the same as the current amplitude unit.

Parameter <level> Real

Explanation

Return The query returns the level value in scientific notation.

For example

```
TRIGger:TIMEout:LEVel 0.16 /* Set the trigger level to 160mV*/
TRIGger:TIMEout:LEVel? /* The query returns 1.600000e-01*/
```

3.31 Timeout trigger polarity **TRIGger:TIMEout:POLarity**

Syntax TRIGger:TIMEout:POLarity <polarity>
TRIGger:TIMEout:POLarity?

Description Set or query the edge type in timeout trigger

Parameter <polarity> Discrete {POSItive|NEGAtive}

Explanation

Return

For example

```
TRIGger:TIMEout:POLarity POSItive /*Set the pulse polarity to POSTive */
TRIGger:TIMEout:POLarity? /* The query returns POSItive */
```

4. Acquire Commands

4.1 Acquire mode **ACQUIRE:MODE**

Syntax ACQUIRE:MODE <mode>
ACQUIRE:MODE?

Description Set or query The current acquire status

Parameter <mode> Discrete {ROLL|SCAN|NORMAL}

Explanation

ROLL: scroll mode.

SCAN: scan mode.

NORMAL: normal mode.

Return

For example ACQuire:MODE SCAN /* Set the acquire status is SCAN*/
 ACQuire:MODE? /* The query returns SCAN*/

4.2 Acquire depth ACQuire:MDEPth

Syntax ACQuire:MDEPth <mdep>
 ACQuire:MDEPth?

Description Set or query the memory depth of the oscilloscope (namely the number of waveform points that can be stored in a single trigger sample). The default unit is pts (points)

Parameter <mdep> Discrete

Explanation The following equation describes the relationship among memory depth, sample rate, and sample time:

$$\text{Memory Depth} = \text{Sample Rate} \times \text{Sample time}$$

Memory depth corresponding index values are as follows:

Index value	Memory Depth 1.6K
0	16K
1	160K
2	1.6M
3	16M
4	32M
5	64M
6	128M

Return The query returns the actual number of points (integer) index value

For example ACQuire:MDEPth 2 /*Set the memory depth to 160K*/
 ACQuire:MDEPth? /* The query returns 2*/

4.3 Acquire stop ACQUIRE:STOP

Syntax ACQUIRE:STOP

Description Trap collect raw data points.

Parameter

Explanation

Return

For example

```
ACQUIRE:STOP /* Interrupt reading raw data points collected */
```

5. Self-calibration Commands

5.1 Calibrate start CALIBRATE:START

Syntax CALIBRATE:START

Description The oscilloscope starts to execute self-calibration.

Parameter

Explanation The oscilloscope automatically calibration.

Return

For example CALIBRATE:START /*calibrate start*/

5.2 Calibrate state CALIBRATE:STATE?

Syntax CALIBRATE:STATE?

Description

Parameter The current state of calibrate.

Explanation String interpreted as follows:
data[0]: The current calibration channel mode.
data[1]: Currently it is calibrated channel.
data[2]-data[3]: The current index value being calibrated voltage gear.

	data[4]: The calibration status of the current calibration.
	data[5]: Currently the location of the calibration.n
	data[6]: The results of the automatic calibration.
	data[7]-data[9]: Reserved bits.
Return	Returns a string currently being calibrated state.
For example	CALibrate:STAtE? < 4307001000 >

5.3 Calibrate stop **CALibrate:STOP**

Syntax	CALibrate:STOP
Description	Interrupt the self-calibration at any time.
Parameter	
Explanation	Interrupt instruction of the calibration process.
Return	
For example	CALibrate:STOP /* Stop calibration status */

6. AUTOSET

Syntax	AUTOSET
Description	Enable the waveform auto setting function. The oscilloscope will automatically adjust the vertical scale, horizontal timebase, and trigger mode according to the input signal to realize optimum waveform display. This command is equivalent to pressing the AUTO key at the front panel.
Parameter	
Explanation	Theoretically, waveform auto setting function requires that the frequency of sine is no lower than 41Hz; the duty cycle should be greater than 1% and the amplitude must be at least 20mVpp for square (the probe ratio is 1X). When the pass/fail function is enabled (see

the :MASK:ENABLE command), if you sent this command, the oscilloscope will disable the pass/fail function firstly and then execute the waveform auto setting function.

When the waveform record function is enabled or during the playback of the recorded waveform, this command is invalid.

Return

For example

7. RUN/STOP Setting

Syntax	RUNning <bool> RUNning?
Description	When the waveform record function is enabled or during the playback of the recorded waveform, these commands are invalid.
Parameter	<bool> Bool {{0 OFF}} {1 ON}}
Explanation	RUN The RUN command starts the oscilloscope STOP the STOP command stops the oscilloscope These commands are equivalent to pressing the RUN/STOP key at the front panel.
Return	The query returns ON or OFF
For example	RUNning ON /*Set oscilloscope status is RUN*/ RUNning? /* The query returns ON*/

8. Reset *RST

Syntax	*RST
Description	Restore the oscilloscope to factory settings.
Parameter	
Explanation	On this command, the scope restore factory settings
Return	

For example *RST /* Reset */

9. Single trigger SINGle:Trig

Syntax SINGle:Trig

Description Set the oscilloscope to the single trigger mode.

Parameter

Explanation In the single trigger mode, the oscilloscope triggers once when the trigger conditions are met and then stops. When the waveform record function is enabled or during the playback of the recorded waveform, this command is invalid.

Return

For example SINGle:Trig /* Setting a trigger */

10. Get all of the one-time parameter setting state SETUp:ALL?

Syntax SETUp:ALL?

Description Get all at once state power needed.

Parameter

Explanation Gets a string of one-time state of the boot.

Return String contains the settings used between the state ";" separated.

For example

Remark

Channel Enable:(For more details, please see [1.3 Channel switch CHANnel<n>:DISPlay](#)).

Channel Coupling:(For more details, please see [1.2 Channel Coupling CHANnel<n>:COUPling](#)).

Channel bandwidth limit:(For more details, please see[1.1 Bandwidth limitations](#)
[CHANnel<n>: BWLimit](#)).

Probe ratio:(For more details, please see[1.8 Channel probe ratio](#)
[CHANnel<n>:PROBe](#)).

Voltage division:(For more details, please see[1.7 Channel voltage gear](#)
[CHANnel<n>:SCALe](#)).

Channel Offset: Waveform with respect to the center line (zero, up is positive, down is negative) shift (a large cell represents 25 value), such as channel 1 offset value is 75, representing the upward shift in the centerline of three a large grid.

Channel inversion:(For more details, please see[1.4 Inverted waveform display](#)
[CHANnel<n>:INVert](#)).

Operating status:(For more details, please see[7. RUN/STOP Setting](#)).

Acquisition mode:(For more details, please see[4.1 Acquire mode](#)
[ACQuire:MODE](#)).

Acquisition type: Return Value There are three: NORMAL representative of the general collection; PEAK represents the peak collection; AVERAGE represents the average acquisition.

Trigger mode:(For more details, please see[3.4 Trigger sweep TRIGger:SWEep](#)).

When the base value:(For more details, please see[2.2 Main timebase scale](#)
[TIMEbase:MAIN:SCALE](#)).

Frequency meter channel source: the return value of five, the first four are 0-3, 1-4,4 representatives do not represent the channel meter off.

Sampling rate: value represents the current sample rate of return.

Memory depth:(For more details, please see[4.2 Acquire depth](#)
[ACQuire:MDEPth](#)).

Trigger Type:(For more details, please see[3.1 Trigger mode TRIGger:MODE](#)).

Trigger Time:(For more details, please see[3.2 Trigger time TRIGger:TIME](#)).

Edge Trigger source:(For more details, please see[3.5 Edge-triggered trigger source TRIGger:EDGE:SOURce](#)).

Edge Trigger level:(For more details, please see[3.7 Edge trigger level TRIGger:EDGe:LEVel](#)).

Edge Trigger Polarity:(For more details, please see[3.11 Pulse trigger polarity TRIGger: PULSe:POLarity](#)).

Pulse Trigger source:(For more details, please see[3.8 Trigger pulse source TRIGger:PULSe:SOURce](#)).

Pulse Width trigger level:(For more details, please see[3.12 Pulse Trigger level TRIGger:PULSe:LEVel](#)).

Pulse Trigger Polarity:(For more details, please see[3.11 Pulse trigger polarity TRIGger: PULSe:POLarity](#)).

Pulse Trigger conditions:(For more details, please see[3.9 Pulse Trigger conditions TRIGger:PULSe:WHEN](#)).

Pulse width trigger:(For more details, please see[3.10 Trigger pulse width trigger value TRIGger:PULSe:WIDth](#)).

Overtime Trigger Source:(For more details, please see[3.27 Timeout trigger source TRIGger:TIMEout:SOURce](#)).

Timeout Trigger level:(For more details, please see[3.30 Timeout trigger level TRIGger:TIMEout:LEVel](#)).

Overtime Trigger Polarity:(For more details, please see[3.31 Timeout trigger polarity TRIGger:TIMEout:POLarity](#)).

Overtime Trigger Width:(For more details, please see[3.28 Timeout trigger width TRIGger:TIMEout:WIDth](#)).

Slope Trigger Source:(For more details, please see[3.13 Trigger Slope trigger source TRIGger:SLOPe:SOURce](#)).

Slope trigger level (1):(For more details, please see[3.16 Slope trigger alevel TRIGger:SLOPe:ALEVel](#)).

Slope trigger level (2):(For more details, please see[3.17 Slope trigger blevel TRIGger:SLOPe:BLEVel](#)).

Slope Trigger Polarity:(For more details, please see[3.18 Slope trigger polarity TRIGger:SLOPe:POLarity](#)).

Slope trigger condition:(For more details, please see[3.14 Slope Trigger trigger condition TRIGger:SLOPe:WHEN](#)).

Slope Trigger width:(For more details, please see[3.10 Trigger pulse width trigger value TRIGger:PULSe:WIDth](#)).

Video Trigger source:(For more details, please see[3.20 Trigger video trigger source TRIGger:VIDeo:SOURce](#)).

Video trigger level:(For more details, please see[3.23 Video trigger level TRIGger:VIDeo:LEVel](#)).

Video Trigger Polarity:(For more details, please see[3.24 Video trigger polarity TRIGger:VIDeo:POLarity](#)).

Video triggering standard:(For more details, please see[3.26 Video trigger standard TRIGger:VIDeo:STANdard](#)).

Video trigger mode:(For more details, please see[3.21 Video trigger mode TRIGger:VIDeo:MODE](#)).

Video trigger lines:(For more details, please see[3.25 Video trigger line TRIGger:VIDeo:LINE](#)).

Digital channels D0-D7 switch status:(For more details, please see[1. LA D0-D7 switch status LA:POD1:STATe](#)).

Digital channels D8-D15 switch status:(For more details, please see[2. LA D8-D15 switch status LA:POD2:STATe](#)).

D0-D7 digital channel threshold voltage:(For more details, please see[3. LA Custom threshold voltage LA:POD1:THReshold:USERVOLT](#)).

D8-D15 digital channel threshold voltage:(For more details, please see[4. LA Custom threshold voltage LA:POD2:THReshold:USERVOLT](#)).

11. WAVEform

11.1 Get display data **WAVEform:DATA:DISP**

Syntax

WAVEform:DATA:DISP

Description	PC display screen display data.
Parameter	
Explanation	Get all the data display mode scanning, scrolling comprising
Return	Returns a string containing the waveform data packet header
For example	WAVEform:DATA:DISP /* Get display data */
Remark	Analytical see the waveform data packet Appendix

11.2 Get all the data **WAVEform:DATA:ALL**

Syntax	WAVEform:DATA:ALL
Description	Get any data storage case.
Parameter	
Explanation	All waveform data to obtain a large storage mode (memory depth> 1.6K) under.
Return	Returns a string containing the waveform data packet header
For example	WAVEform:DATA:ALL /* Get all data */
Remark	Analytical see the waveform data packet Appendix

12. SYSTem

12.1 Modify the system IP address **SYSTem:IP**

Syntax	SYSTem:IP <addr> SYSTem:IP?
Description	Set or query IP address of the system.
Parameter	<addr>: 32-bit ip address
Explanation	When setting the IP address, 32 IP address, each with eight "," separated.

Return The query returns The current IP address.

For example

SYSTem:IP? 10.0.0.129 /* Get to the current IP address 10.0.0.129*/

SYSTem:IP 192,168,1,10 /* Set the current IP address to192.168.1.10*/

Remark Before you modify the IP address, you need to get about the current IP address

12.2 Get the system version number SYSTem:VERSion?

Syntax SYSTem:VERSion?

Description Query system version number

Parameter

Explanation The version number consists of three parts, namely 'arm' version information, 'fpga' version information, 'usb' version information.

Return The query returns current version number.

For example

SYSTem:VERSion?/*The query returns current version number is Ver001.001.001*/

Source section

1. Set and query the status of source channel

SOURce:OUTPut

Syntax	SOURce:OUTPut <bool> SOURce:OUTPut?
Description	Turn on or off the output of the specified source channel, or query the status of the output of the specified source channel.
Parameter	<bool> Bool {{OFF}}{ON}}
Explanation	
Return	The query returns OFF or ON.
For example	

```
SOURce:OUTPut OFF /* Set the output state of channel1 to OFF*/  
SOURce:OUTPut? /* The query returns OFF*/
```

2. Set and query the type of source channel

SOURce:FUNction:TYPE

Syntax	SOURce:FUNction:TYPE <wave> SOURce:FUNction:TYPE?
Description	Set or query the type of source channel
Parameter	<wave> Discrete {{SINusoid},{RAMP},{SQUare},{TRape},{DC},{EXP},{AM/FM}, {ARB},{GAUSs}}
Explanation	
Return	Returns one parameter string.
For example	

SOURce:FUNcTion:TYPE SINusoid /*Set the output waveform of source to SINusoid*/
SOURce:FUNcTion:TYPE? /* The query returns SINusoid*/

3. Set and query the frequency of source channel

SOURce:OUTPut:FREQuency

Syntax SOURce:OUTPut:FREQuency <freq>
SOURce:OUTPut:FREQuency?

Description Set or query the type of source channel.

Parameter <freq> Integer

Explanation The default unit is Hz

Return The query returns frequency of current source output.

For example

SOURce:OUTPut:FREQuency 1000 /*Set frequency of source output to 1000Hz*/
SOURce:OUTPut:FREQuency? /* The query returns 1000 */

4. Set and query the amp of source channel

SOURce:OUTPut:AMP

Syntax SOURce:OUTPut:AMP <amp>
SOURce:OUTPut:AMP?

Description Set or query the amp of source channel.

Parameter <amp> Integer

Explanation The default unit is mv

Return The query returns amp of current source output.

For example

SOURce:OUTPut:AMP 1000 /* Set amp of source output to 1000mv*/
SOURce:OUTPut:AMP? /* The query returns 1000*/

5. Set and query the offset of source channel

SOURce:OUTPut:OFFSet

Syntax	SOURce:OUTPut:OFFSet <offset> SOURce:OUTPut:OFFSet?
Description	Set or query the offset of source channel.
Parameter	<offset> Integer
Explanation	The default unit is mv
Return	The query returns offset of current source output.

For example

```
SOURce:OUTPut:OFFSet 1000 /* Set offset of source output to 1000mv*/  
SOURce:OUTPut:OFFSet? /* The query returns 1000 */
```

6. Set and query the duty of source channel

SOURce:OUTPut:Duty

Syntax	SOURce:OUTPut:DUTY <duty> SOURce:OUTPut:DUTY?
Description	Set or query the duty of source channel.
Parameter	<duty>Integer
Explanation	Ramp, Square, Tape has a duty cycle range of 0% - 100%.
Return	The query returns duty of current source output.

For example

```
SOURce:OUTPut:DUTY 60 /* Set duty of source output to 60%*/  
SOURce:OUTPut:DUTY? /* The query returns 60*/
```

7. Set and query the Trapezoidal wave rises duty of source channel

SOURce:OUTPut:TRAPe:DUTY:RISE

Syntax	SOURce:OUTPut:TRAPe:DUTY:RISE <duty> SOURce:OUTPut:TRAPe:DUTY:RISE?
Description	Set or query the trapezoidal wave rises duty of source channel.
Parameter	<duty> Integer
Explanation	Set or query the trapezoidal wave rises duty of source channel, range of 0% - 100%.
Return	The query returns trapezoidal wave rises duty of current source output.

For example

SOURce:OUTPut:TRAPe:DUTY:RISE 60/* Set duty of source output to 60%*/

SOURce:OUTPut:TRAPe:DUTY:RISE? /* The query returns 60*/

8. Set and query the Trapezoidal wave falls duty of source channel

SOURce:OUTPut:TRAPe:DUTY:FALL

Syntax	SOURce:OUTPut:TRAPe:DUTY:FALL <duty> SOURce:OUTPut:TRAPe:DUTY:FALL?
Description	Set or query the trapezoidal wave falls duty of source channel.
Parameter	<duty> Integer
Explanation	Set or query the trapezoidal wave falls duty of source channel, range of 0% - 100%.
Return	The query returns trapezoidal wave rises duty of current

source output.

For example

SOURce:OUTPut:TRAPe:DUTY:FALL 60/* Set duty of source output to 60%*/

SOURce:OUTPut:TRAPe:DUTY:FALL? /* The query returns 60*/

9. Set and query the Trapezoidal wave high duty of source channel

SOURce:OUTPut:TRAPe:DUTY:HIGH

Syntax	SOURce:OUTPut:TRAPe:DUTY:HIGH <duty> SOURce:OUTPut:TRAPe:DUTY:HIGH?
Description	Set or query the trapezoidal wave high duty of source channel.
Parameter	<duty> Integer
Explanation	Set or query the trapezoidal wave high duty of source channel, (Rise, High, Fall sum of three and a maximum of 100, minimum 0) range of 0% - 100%.
Return	The query returns trapezoidal wave high duty of current source output.

For example

SOURce:OUTPut:TRAPe:DUTY:HIGH 60/* Set duty of source output to 60%*/

SOURce:OUTPut:TRAPe:DUTY:HIGH? /* The query returns 60*/

10. Set and query the EXP type of source channel

SOURce:OUTPut:EXP:TYPE

Syntax	SOURce:OUTPut:EXP:TYPE <type> SOURce:OUTPut:EXP:TYPE?
Description	Set or query the EXP type of source channel.
Parameter	<type> Discrete {{Rise},{Fall}}

Explanation

Return Returns one parameter string.

For example

```
SOURce:OUTPut:EXP:TYPE Rise /* Set the Exp type of source output to Rise*/  
SOURce:OUTPut:EXP:TYPE? /* The query returns Rise*/
```

11. Set and query output signal source Exp spike accounted for a proportion of the cycle time

SOURce:OUTPut:EXP:T

Syntax SOURce:OUTPut:EXP:T <time>

SOURce:OUTPut:EXP:T?

Description and query output signal source Exp spike accounted for a proportion of the cycle time

Parameter <time> Integer

Explanation The default unit is ms

Return The query returns Exp cycle time of current source output.

For example

```
SOURce:OUTPut:EXP:T 200/* Set the Exp cycle time of source output to 200ms*/  
SOURce:OUTPut:EXP:T? /* The query returns 200*/
```

12. Set and query the AM/FM type of source channel

SOURce:OUTPut:AM/FM:TYPE

Syntax SOURce:OUTPut:AM/FM:TYPE <type>

SOURce:OUTPut:AM/FM:TYPE?

Description Set or query the AM/FM type of source channel.

Parameter <type> Discrete {{FM},{AM}}

Explanation

Return Returns one parameter string.

For example

SOURce:OUTPut:AM/FM:TYPE FM/* Set the AM/FM type of source output to FM*/

SOURce:OUTPut:AM/FM:TYPE? /* The query returns FM*/

13. Set and query the AM/FM high frequency of source channel SOURce:OUTPut:AM/FM:FO

Syntax	SOURce:OUTPut:AM/FM:FO <freq> SOURce:OUTPut:AM/FM:FO?
Description	Set or query the AM/FM high frequency of source channel.
Parameter	<freq> Integer
Explanation	The default unit is Hz
Return	The query returns AM/FM high frequency of current source output.

For example

SOURce:OUTPut:AM/FM:FO 1000/*Set the AM/FM high freq of source output to 1000Hz*/

SOURce:OUTPut:AM/FM:FO? /* The query returns 1000*/

14. Set and query the AM/FM modulation depth of source channel SOURce:OUTPut:AM/FM:DEPTH

Syntax	SOURce:OUTPut:AM/FM:DEPTH <depth> SOURce:OUTPut:AM/FM:DEPTH?
Description	Set or query the AM/FM modulation depth of source channel.
Parameter	<depth> Integer
Explanation	range of 0% - 100%.
Return	The query returns AM/FM modulation depth of current source output.

For example

SOURce:OUTPut:AM/FM:DEPT_h 10/* Set the AM/FM modulation depth of source output to 10%*/

SOURce:OUTPut:AM/FM:DEPT_h? /* The query returns 10*/

15. Set and query the AM/FM MAXImfreq of source channel

SOURce:OUTPut:AM/FM:MAXImfreq

Syntax	SOURce:OUTPut:AM/FM:MAXImfreq <freq> SOURce:OUTPut:AM/FM:MAXImfreq?
Description	Set or query the AM/FM MAXImfreq of source channel.
Parameter	<freq> Integer
Explanation	The default unit is Hz
Return	The query returns AM/FM MAXImfreq of current source output.

For example

SOURce:OUTPut:AM/FM:MAXImfreq 1000/* Set the AM/FM MAXImfreq of source output to 1000Hz*/

SOURce:OUTPut:AM/FM:MAXImfreq? /* The query returns 1000 */

16. Trigger signal source

SOURce:TRIGger:SOURce

Syntax	SOURce:TRIGger:SOURce <source> SOURce:TRIGger:SOURce?
Description	Set or query the trigger signal source is internal or external source
Parameter	<source> Discrete { INTernal EXTernal }
Explanation	

Return The query returns INTERNAL、EXTERNAL

For example

```
SOURce:TRIGger:SOURce EXTERNAL /*Set the trigger source to EXTERNAL*/
```

```
SOURce:TRIGger:SOURce? /* The query returns EXTERNAL */
```

17. Polarity of external trigger source

SOURce:TRIGger:EXTER:SLOPe

Syntax SOURce:TRIGger:EXTER:SLOPe < polarity >

SOURce:TRIGger:EXTER:SLOPe?

Description Set or query the polarity of external trigger source.

Parameter <polarity> Discrete POSITIVE NEGATIVE

Explanation

Return The query returns POSITIVE or NEGATIVE

For example

```
SOURce:TRIGger:EXTER:SLOPe NEGATIVE /* Set the polarity of external trigger source to NEGATIVE */
```

```
SOURce:TRIGger:EXTER:SLOPe? /* The query returns NEGATIVE*/
```

18. Trigger status of source

SOURce:TRIGger:CONTInue

Syntax SOURce:TRIGger:CONTInue <bool>

SOURce:TRIGger:CONTInue?

Description Set or query the trigger status of source, Whether it is a continuous state.

Parameter <bool> Bool {{OFF}}{ON}}

Explanation

Return The query returns OFF or ON

For example

SOURce:TRIGger:CONTInue ON /* Set the trigger status of source to ON*/

SOURce:TRIGger:CONTInue? /* The query returns ON*/

19. Clear external trigger signal source

SOURce:TRIGger:EXTEr:CLEAr

Syntax	SOURce:TRIGger:EXTEr:CLEAr
Description	When the signal source is external trigger and a continuous mode to clear the external trigger
Parameter	
Explanation	
Return	
For example	SOURce:TRIGger:EXTEr:CLEAr /* Clear external trigger */

20. Trigger signal source SOURce:TRIGger

Syntax	SOURce:TRIGger
Description	When the signal source to manual trigger source, send a command to trigger a
Parameter	
Explanation	Only when the source is a single internal trigger source and is effective
Return	
For example	SOURce:TRIGger /* Setting a trigger */

21. Source sync SOURce:SYNC

Syntax	SOURce:SYNC <bool> SOURce:SYNC?
Description	Set and query the synchronization signal source is a square wave output.

Parameter <bool> Bool {{OFF}}|{ON}}

Explanation

Return The query returns OFF or ON.

For example

```
SOURce:SYNC ON /* Synchronization signal source to output a square wave */  
SOURce:SYNC? /* The query returns ON*/
```

22. Arbitrary wave frequency signal

SOURce:FUNction:ARB:FREQuency

Syntax SOURce:FUNction:ARB:FREQuency <freq>

SOURce:FUNction:ARB:FREQuency?

Description Set and query frequency arbitrary waveform signal source

Parameter <freq>Integer

Explanation The default unit is Hz

Return The query returns arbitrary waveform frequency of current source output.

For example

```
SOURce:FUNction:ARB:FREQuency 1000/*Set arb frequency to 1000Hz*/  
SOURce:FUNction:ARB:FREQuency? /* The query returns 1000*/
```

23. Source of arbitrary wave download points

SOURce:FUNction:ARB:POINT?

Syntax SOURce:FUNction:ARB:POINT?

Description Query source of arbitrary wave download points.

Parameter

Explanation

Return The query returns the current signal source of arbitrary wave download points.

For example

SOURce:FUNctIon:ARB:POINt?/*Query source of arbitrary wave download points */

24. Arbitrary wave signal data download

SOURce:DATA:ARB:DAC16:BIN

Syntax	SOURce:DATA:ARB:DAC16:BIN <binary_block_data>
Description	Download arbitrary waveform data.
Parameter	
Explanation	Download arbitrary waveform data, <binary_block_data> denotes the binary data to be downloaded, <binary_block_data> is a binary data block starts with #. For example, “#500200” binary data, the number 5 behind # denotes that the data length information (00200) occupies 5 characters. “200” denotes the number of bytes of the binary data. As each waveform point corresponds to two bytes of binary number(For example, Point 1024 corresponds to the binary number is 0x0400, Data low byte first, high byte, so for the 0004), the number of bytes must be an even number.

Return

For example

25. Get all of the source parameter setting status

SOURce:SETUp:ALL?

Syntax	SOURce:SETUp:ALL? :
Description	Get all of the source parameter setting status.
Parameter	
Explanation	Gets a string of one-time sources of the state.

Return String contains the settings used between the state ";" separated.

For example

```
SOURce:SETUp:ALL?  
OFF;SINusoid;1000;1000;0;50;20;40;20;Rise;10;FM;10000;50;3000;INTe  
rnal;POSItive;ON;0;OFF;PROGram;0
```

Remark

Switching signal source, signal source output type, source output frequency, source output amplitude, source output offset, source output duty cycle, the duty cycle of rising trapezoidal wave, trapezoidal wave high duty cycle, trapezoidal wave fall duty cycle, exponential wave type (up, down), exponential wave time, type of FM/AM(FM, AM), High frequency, modulation depth, maximum deviation, trigger type, trigger polarity, continuous trigger switch, any wave download points, word generator switch, the word function generator, word generator programmed value.

Word generator section

1. Set and query the status of word generator

WORD:OUTPut

Syntax	WORD:OUTPut <bool> WORD:OUTPut?
Description	Open or closed status word generator.
Parameter	<bool> Bool {{OFF}}{ON}}
Explanation	
Return	The query returns ON or OFF.
For example	WORD:OUTPut ON /* Open word generator */ WORD:OUTPut? /* The query returns ON*/

2. Set and query the features of word generator

WORD:FUNction

Syntax	WORD:FUNction <fun> WORD:FUNction?
Description	Set word generator is programmable or just synchronizing signal sources
Parameter	<fun> Discrete PROGram, SYNC
Explanation	
Return	The query returns PROGram or SYNC
For example	WORD:FUNction PROGram /* Set the features of word generator to PROGram*/ WORD:FUNction? /* The query returns PROGram */

3. Set and query the Programmed of value word generator **WORD:PROG**ram

Syntax WORD:PROG <0xffff >

WORD:PROG?

Description Set or query the the Programmed of value word generator.

Parameter 0xffff represents a 16-bit word generator programmed value

Explanation

Return The query returns Programmed of value word generator.

For example

```
WORD:PROG 0xffff /* Set the the Programmed of value word generator to 0xffff*/
```

```
WORD:PROG? /* The query returns 65535*/
```

Logic analyzers section

1. LA D0-D7 switch status **LA:POD1:STaTe**

Syntax	LA:POD1:STaTe <enable> LA:POD1:STaTe?
Description	Set or query D0-D7 switch status, POD1 represents D0-D7.
Parameter	<enable> Discrete {OFF ON}
Explanation	OFF: shut down ON: turn on
Return	
For example	

```
LA:POD1:STaTe ON /*Set switch state D0-D7 to ON*/  
LA:POD1:STaTe? /* The query returns ON*/
```

2. LA D8-D15 switch status **LA:POD2:STaTe**

Syntax	LA:POD2:STaTe <enable> LA:POD2:STaTe?
Description	Set or query D8-D15 switch status,POD2 represents D8-D15.
Parameter	<enable> Discrete {OFF ON}
Explanation	OFF: shut down ON: turn on
Return	
For example	

```
LA:POD2:STaTe ON /*Set switch state D8-D15 to ON*/  
LA:POD2:STaTe? /* The query returns ON*/
```

3. LA Custom threshold voltage

LA:POD1:THReshold:USERVolt

Syntax	LA:POD1:THReshold:USERVolt <volt> LA:POD1:THReshold:USERVolt?
Description	Set or query the threshold of the specified channel group, POD1 represents D0-D7.
Parameter	<volt> Real Custom threshold voltage value.
Explanation	The default unit is v.
Return	
For example	LA:POD1:THReshold:USERVolt 2.3 /*Set the threshold of POD1 (D0 to D7) to 2.3V*/ LA:POD1:THReshold:USERVolt? /* The query returns 2.300000e+00*/

4. LA Custom threshold voltage

LA:POD2:THReshold:USERVolt

Syntax	LA:POD2:THReshold:USERVolt <volt> LA:POD2:THReshold:USERVolt?
Description	Set or query the threshold of the specified channel group, POD2 represents D8-D15.
Parameter	<volt> Real Custom threshold voltage value.
Explanation	The default unit is v.
Return	
For example	LA:POD2:THReshold:USERVolt 2.3/*Set the threshold of POD2(D8 to D15)to 2.3V*/ LA:POD2:THReshold:USERVolt? /* The query returns 2.300000e+00*/

5. LA digital channels D0-D15 switch status

LA:SOURce

Syntax	LA:SOURce <n>,<state>
Description	Sets the specified digital channels {D0-D15} switch to any channel
Parameter	<n> Discrete {0--15}, <state> Bool {0 1}
Explanation	D0-D15 total of 16 channels, 0 is off, 1 is open
Return	
For example	

```
LA:SOURce D0,1    /* Setting logic analyzer channel D0 Open */
```

Appendix

SCPI Agreement Remarks:

(1) all set to send commands only, not to acquire

(2) Get all commands sent reacquisition

(3) to obtain waveform data packet data [x] be interpreted as follows:

data[0]-data[1] (2 digits): #9

data[2]-data[10] (9 digits): Indicates that the current byte packet length

data[11] (1 digit): It indicates the current operating status

data[12] (1 digit): It indicates trigger status

data[13]-data[21] (9 digits): It represents the amount of data bytes of total length

data[22]-data[30] (9 digits): He said that it has uploaded the data length in bytes

data[31]-data[34] (4 digits): Represents the channel offset 1

data[35]-data[38] (4 digits): Represents the channel offset 2

data[39]-data[42] (4 digits): Represents the channel offset 3

data[43]-data[46] (4 digits): Represents the channel offset 4

data[47]-data[53] (7 digits): Represents the channel voltage 1

data[54]-data[60] (7 digits): Represents the channel voltage 2

data[61]-data[67] (7 digits): Represents the channel voltage 3

data[68]-data[74] (7 digits): Represents the channel voltage 4

data[75]-data[78] (4 digits): It represents the channel [1-4] Enable

data[79]-data[87] (9 digits): It indicates a sampling rate

data[88]-data[93] (6 digits): Represents a multiple sampling (only in memory depth > 1.6K suspended helpful)

data[94]-data[102] (9 digits): It displays the current trigger time frame

data[103]-data[111] (9 digits): The current frame display data acquisition start time point of the start point (> 1.6K pause when only useful in memory depth)

data[112]-data[114] (3 digits): It represents digital channels (D0-D7) of the switching state

data[115]-data[117] (3 digits): It represents digital channels (D8-D15) of the switching state

data[118]-data[126] (9 digits): Reserved bit

data[127] (1 digit): version number

data[128]-data[x] : Indicates that the current waveform data corresponding to the data header